

HDTV WIRELESS HEADPHONES KIT

with Bluetooth® Audio Transmitter and Bluetooth® Headphones



Operation Manual

MTH9-1001-BLK V4.0 1020

Introduction

This HDTV Wireless Headphones Kit with Bluetooth® Audio Transmitter and Bluetooth® Headphones conveniently streams audio from TV's and gaming systems to Bluetooth® headphones, soundbars or speakers up to 33ft away.

Features

- Add Bluetooth audio capability to your TV or home stereo
- · Stream audio up to 33ft
- · Watch TV without disturbing others
- · Easy installation and pairing

What's Included

- · Bluetooth Audio Transmitter
- Bluetooth Headphones
- 3.5mm Aux Cable 1.5ft (0.5m)
- · Micro USB Charging Cable x2 3ft (1m) each
- USB Wall Charger
- · Self-adhesive Transmitter Mount
- User Manual x1 pc

Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's warranty or authority to operate the equipment. Risk of explosion if the battery is replaced by an incorrect type. Wall mounting height is less than 2M.

Controls, at a Glance







STEP 1: Charge

For best performance, it is recommended to fully charge both devices before the first use (estimated charge time: 3hrs each)

- Using included (or any) micro USB cable and USB power source, charge both your Monster Bluetooth Transmitter and Monster Bluetooth Headphones until full.
 - LED charging indicator (next to the USB port) Solid RED - charging / GREEN - fully charged
 - LED indicator (next to the USB port) Solid RED - charging / OFF - fully charged

Note: The Transmitter includes an optional, peel-and-stick mounting bracket that can conveniently attach it to the back of your TV.

- Connect the Transmitter to an audio source, like a TV or home stereo, using the 3.5mm audio jack and the included 3.5mm Aux Cable. Be sure that it is connected to the AUDIO OUTPUT lack of the audio source, not an input.
 - Note: After connecting the Transmitter, you may need to adjust your TV's audio output to select the 3.5mm output.
- For prolonged use in this location, connect the transmitter to one of your TV's USB ports, or a separate USB power source, using the USB cable.

Turn on the Transmitter by switching the power switch on the side to the "ON" position. The Bluetooth LED indicator will illuminate solid blue.

STEP 3: Auto Pair the Bluetooth Headphones



- Press+Hold the Multifunction Button I on the Headphones for 3 seconds to turn on the Bluetooth headphones, you will hear a 3-note chime indicating that it has turned on.
- The LED indicator with begin quickly flashing red and blue indicating it has entered Auto Pairing Mode. The Headphones and the Transmitter will automatically pair with each other. You will hear a 2-note chime indicating that they have paired successfully and the LEDs will pulse blue.
 - Bluetooth indicator (on the button)
 Solid Blue ready to pair / BLUE slow flash paired
 - LED indicator (next to the USB port)

 RED&BLUE fast flash pairing / BLUE slow flash paired

Note: Auto Pair should take no more than 5 seconds to complete. If you have not heard the 2-note chime indicating pairing success, **Press** the

button on the Transmitter **ONCE**.

DO NOT press+hold this button as it may reset the device.

Pairing with Other Devices

For info on manually pairing the Transmitter to a different Bluetooth Audio Device, like earbuds or speakers, or manually pairing the Headphones to a different Bluetooth Audio Source, like a tablet or phone, please see pg 6.

MONSTER®





Pairing To Other Devices

Note: The headphones and transmitter can each only connect to one device at a time.

Manually Pair the Transmitter to a different Bluetooth Audio Device

If desired, the Transmitter can stream audio to any other Bluetooth enabled audio device, like earbuds, headphones, or speakers. Ensure the Headphones are OFF before re-pairing the Transmitter.

- To manually enter pairing mode on the Transmitter, Press the \$\\$ button ONCE. The Bluetooth LED indicator will flash blue quickly indicating it has entered Pairing Mode.
- Activate pairing mode on your Bluetooth audio device (follow the individual instructions for your device). The Transmitter will locate and automatically pair to the available device, allow up to 20 seconds for the Transmitter to pair.

Manually Pair the Headphones to a different Bluetooth Audio Source

If desired, the Bluetooth Headphones can be paired to any Bluetooth enabled device, like phones, tablets, or computers. Ensure the Transmitter is OFF before re-pairing the Headphones.

- Enable Bluetooth search mode on your audio device (follow the individual instructions for your device)
- Turn on the Bluetooth headphones by pressing and holding the Multifunction Button ►II for 3 seconds, you will hear a 3-note chime indicating that it has turned on. The LED indicator will begin quickly flashing blue and red indicating it has entered Auto Pairing Mode.
- Ocate and select device "MONSTER MTH9-1001" in your device's Bluetooth list to complete pairing

Headphones Operation

- Press+Hold the Multifunction Button ►II for 3 seconds to turn on the Bluetooth headphones. (If the Transmitter is ON, the Headphones will automatically reconnect, you will hear a 2-note chime indicating success.)
- Use the buttons to control your audio. You will have different controls based on what device you are connected to:





Press+Hold → + Button to raise the volume
Press +III Button to lower the volume
Press ▶II Button to play/pause audio and to
answer/end phone calls

Press ► + Button to change to the next track

Press - ■ Button to change to the previous track

To power down the headphones, hold the Multifunction Button ▶II for 5 seconds, the LED light indicator will flash red 3 times and then remain off. You will hear a 4-note chime indicating that they have successfully powered off.

To Use as Wired Auxiliary Headphones:

Plug a 3.5mm audio cable into the Aux jack (additional cable not included). The headphones will automatically switch from "Bluetooth" mode to "Auxiliary" mode and power off to conserve battery. The Headphones do not need to be ON in Aux mode. Note: Volume and music control buttons on the headphones will not function while in Aux mode.

Safety Instructions

Please read and understand all instructions before using this product. If damage is caused by failure to follow the instructions. this warranty is null and void.

- · Keep these instructions.
- Do not drop, puncture, or disassemble this product.
- Do not expose this product to dripping or splashing of drinks or liquids of any kind.
- Avoid long exposure to direct sunlight, which may cause damage.
- Do not expose this product to open flames.
- Do not use the product in a strong magnetic field.
- Use a clean, soft cloth to clean. Do not use any corrosive cleaners/oils to clean.
- Do not attempt to repair the device or open the unit as this will void the warranty.

Customer Service



1 Year Limited Warranty Scan QR code for warranty information





866-246-2008



customerservice@monsterilluminessence.com

In the event this product becomes defective, please do not return this product to your retailer.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed or mobile condition. The minimum separation distance is 20cm.

The Illustrated products and specifications may differ slightly from those supplied. The M Monster logo is a registered trademark of Monster, inc. or its subsidiaries in the U.S. and other countries and are used under license. All other brand names are trademarks of their respective owners Neither Jern Accessories, Inc. nor Monster, Inc. is affiliated with the respective owners of their trademarks. Licensed and Manufactured by Jern Accessories. Inc. South Plainfield. NJ 07800. Made in China.