



RGB+W

Multicolor + Multiwhite LED Light Strip
with Remote Control

Operation Manual

MODEL MLB7-1027

V4.0 0623

Introduction

This Multi-color/Multi-white LED strip is easy to install, easy to use, and is ideal for adding ambient backlighting behind your TV or computer monitor for a great movie or gaming experience

Features

- USB powered from any 5V standard USB port
- Self-adhesive backing for easy application
- Color changing and flash modes with controllable brightness adjustment
- 44 RGB color and 44 warm white LED lights for multi-color and multi-white lighting
- 6.5ft (2m) length fits TV's up to 65" to create ambient backlighting
- Remote control works up to 26 feet away
- Plug and play

What's Included

- 6.5ft RGBW LED Light Strip
- IR Remote Control with battery (1 x 3V battery, CR2025*)
- User Manual x1 pc

Safety Instructions

Please read and understand all instructions before using this product. If damage is caused by failure to follow the instructions, this warranty is null and void.


- Keep these instructions.
- Do not drop, puncture, or disassemble this product.
- Do not expose this product to dripping or splashing of drinks or liquids of any kind.
- Avoid long exposure to direct sunlight, which may cause damage.
- Do not expose this product to open flames.
- Do not use the product in a strong magnetic field.
- Use a clean, soft cloth to clean. Do not use any corrosive cleaners/oils to clean.
- Do not attempt to repair the device or open the unit as this will void the warranty.

Get Started

- 1 Clean the surface you intend to stick the LED Light to
- 2 Peel beginning of adhesive backing off and firmly stick LED Light onto the mounting surface (be careful to peel off only the backing and not the adhesive)
- 3 Peel off more of the adhesive backing as you mount the LED Light, pressing and holding each section firmly against the surface
- 4 Remove the tab from the battery compartment of the remote control
- 5 Connect the USB cable to a USB wall charger or a power bank (1A adapter required – not included)

Installation Notes:

- 1 For best mounting results, place adhesive onto desired surface with ONE attempt. Reapplying multiple times will not guarantee secure mounting onto surface.
- 2 Make sure the desired location is close enough to a power source like a TV's USB port or a wall outlet with a 1A USB adapter (not included)
- 3 For optimal performance, place IR receiver in a location away from the IR receiver on the TV to avoid interference from the TV remote control signal
- 4 For backlighting a TV or monitor, follow the mounting diagram below:



MONSTER™



Operation Manual

MODEL MLB7-1027

V4.0 0623

Controls, at a Glance



IR Remote

①	ON/OFF	Turn the product on and off
②	MULTI-WHITE SELECTORS	Select from cool, soft, or warm white
③	MULTI-COLOR SELECTORS	Change the color to match your mood
④	FLASH	Flash color-changing mode
⑤	STROBE	Strobe color-changing mode
⑥	FADE	Fade color-changing mode
⑦	SMOOTH	Smooth color-changing mode
⑧	RESET	Reset to default settings
⑨	DIMMER BUTTONS	Adjust the brightness/intensity

IR Remote Operation

The battery for the remote control has already been installed. Remove and discard the clear plastic pull tab before use.

- 1 Turn on the LED Light by pushing the ON button on the remote control
- 2 Select the desired color or the desired effect by pushing the corresponding button on the remote control
- 3 Set the desired brightness using the buttons to increase/decrease the intensity of color
- 4 Push the OFF button to turn off the LED Light

NOTE: For best operation, point the IR remote towards the IR Receiver at the beginning of the light strip.

Changing the remote control battery:

- 1 The battery compartment is located on the narrow side of the remote control, press the release tab inwards and remove the tray
- 2 Remove the empty battery and insert a 3V battery, type CR2025*, with the positive terminal pointing upwards
- 3 Place the battery compartment back in the remote control so it locks in place

* The listed battery type may differ slightly from what is supplied. When replacing the battery, please verify the actual battery size in the remote control.

Customer Service



1 Year Limited Warranty

Scan QR code for warranty information



866-246-2008



customerservice@monsterilluminescence.com

**In the event this product becomes defective,
please do not return this product to your retailer.**

Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's warranty or authority to operate the equipment.

Specifications

- LED Light (USB): 5V
- output: 2.5W
- length: 6.5ft
- remote control: 3V
(1 x 3V battery, type CR2025*)

* The listed battery type may differ slightly from what is supplied. When replacing the battery, please verify the actual battery size in the remote control.

EN Need the Quick Start Guide in another language?

FR Besoin du guide de démarrage rapide dans une autre langue?

ES ¿Necesita la guía de comienzo rápido en otro idioma?

DE Benötigen Sie die schnellstartanleitung in einer anderen Sprache?

IT Serve la guida rapida in un'altra lingua?

RU Вам нужно Краткое руководство на другом языке?



scan for manuals

rechercher des guides d'utilisation

buscar los manuales

nach Handbüchern scannen

scansione dei manuali

сканирование для руководств

www.monsterilluminescence.com/manuals/

The illustrated products and specifications may differ slightly from those supplied. The M Monster logo is a registered trademark of Monster, Inc. or its subsidiaries in the U.S. and other countries and are used under license. All other brand names are trademarks of their respective owners. Neither Jem Accessories, Inc. nor Monster, Inc. is affiliated with the respective owners of their trademarks. Licensed and Manufactured by Jem Accessories, Inc. Edison, NJ 08817. Made in China.